


Service Manual

FM/MW/LW Stereo Tuner

ST-S2L

[EK], [EF], [EB]



Areas

- * [EK] is available in United Kingdom.
- * [EF] is available in France.
- * [EB] is available in Belgium.

CONTENTS

	Page		Page
SPECIFICATIONS	1	MESURAGES ET RÉGLAGES (Français)	7, 8
TECHNISCHE DATEN	2	BLOCK DIAGRAM	9
CARACTERISTIQUES	2	REPLACEMENT PARTS LIST (Electrical Parts)	10, 12
LOCATION OF CONTROLS	3	CIRCUIT BOARD AND WIRING CONNECTION DIAGRAM	11, 16
DISASSEMBLY INSTRUCTIONS	4	SCHEMATIC DIAGRAM	13 - 15
DIAL CORD INSTALLATION GUIDE	4	REPLACEMENT PARTS LIST (Cabinet & Chassis Parts)	16
MEASUREMENTS AND ADJUSTMENTS (English)	4, 5	EXPLODED VIEW	17, 18
MESSUNGEN UND JUSTIERUNGEN (Deutsch)	5, 6		

English

Specifications

(Specifications are subject to change without notice for further improvement.)

(DIN 45 500)

FM TUNER SECTION

Frequency range	88~108 MHz
Sensitivity	2.0 μ V (IHF, usable)
S/N 30 dB	2.0 μ V (300 Ω), 1.0 μ V (75 Ω)
S/N 26 dB	1.8 μ V (300 Ω), 0.9 μ V (75 Ω)
S/N 20 dB	1.6 μ V (300 Ω), 0.8 μ V (75 Ω)
IHF 46 dB stereo quieting sensitivity	25 μ V/75 Ω
Total harmonic distortion	
MONO	0.15%
STEREO	0.25%
S/N	
MONO	70 dB (78 dB, IHF)
STEREO	65 dB (70 dB, IHF)
Frequency response	20 Hz~15 kHz, +0.5 dB~-1.5 dB
Alternate channel selectivity	
normal ($\pm$ 400 kHz)	60 dB
super narrow ($\pm$ 200 kHz)	20 dB
Capture ratio	1.0 dB
Image rejection at 98 MHz	55 dB
IF rejection at 98 MHz	70 dB
Spurious response rejection at 98 MHz	80 dB
AM suppression	55 dB
Stereo separation	
1 kHz	40 dB
10 kHz	30 dB
Carrier leak	
19 kHz	-30 dB (-35 dB, IHF)
38 kHz	-45 dB (-50 dB, IHF)
Channel balance (250 Hz~6,300 Hz)	$\pm$ 1.5 dB
Limiting point	1.2 μ V

Bandwidth	
IF amplifier	180 kHz
FM demodulator	1000 kHz
Antenna terminals	300 Ω (balanced)
	75 Ω (unbalanced)

AM TUNER SECTION

Frequency range	
MW	525~1605 kHz
LW	145~350 kHz
Sensitivity (S/N 20 dB)	
MW	30 μ V, 250 μ V/m
LW	30 μ V
Selectivity ($\pm$ 10 kHz)	
MW	27 dB (1000 kHz)
LW	35 dB (250 kHz)
Image rejection	
MW	50 dB (1000 kHz)
LW	40 dB (250 kHz)
IF rejection	
MW	40 dB (1000 kHz)
LW	40 dB (250 kHz)

GENERAL

Output voltage	0.3V, (0.6V, IHF)
Power consumption	7W
Power supply	AC 50 Hz/60 Hz, 110V/120V/220V/240V
Dimensions (W×H×D)	430 × 86 × 289 mm
	(16-15/16" × 3-3/8" × 11-3/8")
Weight	3.0 kg
	(6.6 lb.)

Technics

Matsushita Electric Trading Co., Ltd.
P.O. Box 288, Central Osaka Japan

Deutsch

TECHNISCHE DATEN

(Spezifikationen können infolge von Verbesserungen ohne Ankündigung geändert werden.)

(DIN 45 500)**■ UKW-TUNERTEIL**

Wellenbereich	88~108 MHz
Eingangsempfindlichkeit	2,0 μ V (nutzbar nach IHF)
S/R 30 dB	2,0 μ V (300 Ω), 1,0 μ V (75 Ω)
S/R 26 dB	1,8 μ V (300 Ω), 0,9 μ V (75 Ω)
S/R 20 dB	1,6 μ V (300 Ω), 0,8 μ V (75 Ω)
Stereoschaltsschwelle bei 46 dB nach IHF	25 μ V/75 Ω
Gesamtklirrfaktor	
Mono	0,15%
Stereo	0,25%
Geräuschabstand	
Mono	70 dB (78 dB nach IHF)
Stereo	65 dB (70 dB nach IHF)
Frequenzgang	20 Hz~15 kHz (+0,5 dB~-1,5 dB)
Trennschärfe bei Störsender	
normal (± 400 kHz)	60 dB
super narrow (± 200 kHz)	20 dB
Einfangverhältnis	1,0 dB
Spiegelfrequenz-Dämpfung bei 98 MHz	55 dB
ZF-Dämpfung bei 98 MHz	70 dB
Ansprechdämpfung auf Nebenfrequenzen bei 98 MHz	80 dB
AM-Unterdrückung	55 dB
Übersprechdämpfung	
1 kHz	40 dB
10 kHz	30 dB
Trägerrest	
19 kHz	-30 dB (-35 dB nach IHF)
38 kHz	-45 dB (-50 dB nach IHF)
Kanalabweichung (250 Hz ~ 6300 Hz)	$\pm 1,5$ dB
Begrenzereinsatz	1,2 μ V

Bandbreite

ZF-Verstärker	180 kHz
UKW-Demodulator	1000 kHz
Antennenanschluß	300 Ω (symmetrisch)
	75 Ω (unsymmetrisch)

■ AM-TUNERTEIL

Wellenbereiche	
MW	525~1605 kHz
LW	145~350 kHz
Eingangsempfindlichkeit (S/R 20 dB)	
MW	30 μ V, 250 μ V/m
LW	30 μ V
Trennschärfe (± 10 kHz)	
MW	27 dB (1000 kHz)
LW	35 dB (250 kHz)
Spiegelfrequenz-Dämpfung	
MW	50 dB (1000 kHz)
LW	40 dB (250 kHz)
ZF-Dämpfung	
MW	40 dB (1000 kHz)
LW	40 dB (250 kHz)

■ ALLGEMEINE DATEN

Ausgangsspannung	0,3 V, (0,6V, IHF)
Leistungsaufnahme	7W
Netzspannung	Wechselstrom 50 Hz/60 Hz, 110V/120V/220V/240V
Abmessungen (B×H×T)	430 × 86 × 289 mm
Gewicht	3,0 kg

Français

CARACTERISTIQUES

(Sujet à changement sans préavis.)

(DIN 45 500)**■ SECTION SYNTONISATEUR FM**

Gamme de fréquence	88~108 MHz
Sensibilité	2,0 μ V (IHF utilisable)
S/B 30 dB	2,0 μ V (300 Ω), 1,0 μ V (75 Ω)
S/B 26 dB	1,8 μ V (300 Ω), 0,9 μ V (75 Ω)
S/B 20 dB	1,6 μ V (300 Ω), 0,8 μ V (75 Ω)
Sensibilité stéréo au seuil de 46 dB, IHF	25 μ V/75 Ω
Distorsion harmonique totale	
MONO	0,15%
STEREO	0,25%
Signal/Bruit	
MONO	70 dB (78 dB, IHF)
STEREO	65 dB (70 dB, IHF)
Réponse de fréquence	20 Hz~15 kHz, +0,5 dB~-1,5 dB
Sélectivité alternée par canal	
normal (± 400 kHz)	60 dB
super narrow (± 200 kHz)	20 dB
Taux de capture	1,0 dB
Rejection d'image à 98 MHz	55 dB
Rejection FI à 98 MHz	70 dB
Rejection de réponse parasite à 98 MHz	80 dB
Suppression AM	55 dB
Séparation stéréophonique	
1 kHz	40 dB
10 kHz	30 dB
Fuite de porteuse	
19 kHz	-30 dB (-35 dB, IHF)
38 kHz	-45 dB (-50 dB, IHF)
Equilibrage de canaux (250 Hz~6,300 Hz)	$\pm 1,5$ dB
Point de limite	1,2 μ V

Largeur de bande

Amplificateur FI	180 kHz
Démodulateur FM	1000 kHz
Bornes d'antenne	300 Ω (symétrique)
	75 Ω (asymétrique)




■ SECTION SYNTONISATEUR AM

Gamme de fréquence	
PO (MW)	525~1605 kHz
GO (LW)	145~350 kHz
Sensibilité (S/B 20 dB)	
PO (MW)	30 μ V, 250 μ V/m
GO (LW)	30 μ V
Sélectivité (± 10 kHz)	
PO (MW)	27 dB (1000 kHz)
GO (LW)	35 dB (250 kHz)
Réjection d'image	
PO (MW)	50 dB (1000 kHz)
GO (LW)	40 dB (250 kHz)
Réjection FI	
PO (MW)	40 dB (1000 kHz)
GO (LW)	40 dB (250 kHz)

■ DIVERS

Tension de sortie	0,3 V, (0,6V, IHF)
Consommation	7W
Alimentation	CA 50 Hz/60 Hz, 110V/120V/220V/240V
Dimensions (L×H×Pr)	430 × 86 × 289 mm
Poids	3,0 kg


■ LOCATION OF CONTROLS



■ DISASSEMBLY INSTRUCTIONS


● How to remove the cabinet and bottom board

1. Remove the 2 setscrews (Fig. 1 : ❶, ❷) on the side and 4 setscrews (Fig. 1 : ❸ ~ ❹) on the rear of the cabinet.
2. Move the cabinet in the direction of the arrow ➊ in Fig. 1.
3. To remove the bottom board, remove the 8 setscrews (Fig. 2 : ❶ ~ ❷) of the bottom board.
4. Remove the bottom board.
5. When installing the bottom board, the board in the groove provided in the rear panel and then tighten the setscrews. (Fig. 2)



- **How to remove the front panel**


1. Remove the cabinet (Refer to the procedures 1 to 2 of "How to remove" for cabinet.)
2. Remove the tuning knob.
3. Remove the 6 setscrews (Fig. 2: ⑫ and ⑮ ~ ⑲) of the front panel.



■ DIAL CORD INSTALLATION GUIDE

For threading a fresh cord, proceed as follows.

1. Prepare a fresh cord more than 180 cm (70-15/16") in length.
2. Bring the variable capacitor into a state where the drum is completely turned to the right (maximum capacity and lowest frequency for the variable capacitor).
3. Direct the cord in the order from 1 to 8.
4. Stretch the cord in such a tension as the spring length is elongated by 1.5 times that of the original state.
5. Fix the knot of the cord with the bond.



■ MEASUREMENTS AND ADJUSTMENTS English

Be sure to make the adjustments of MW and LW in the order of step No.

● Setting and Equipment used

- [illegible]

7. FM muting & mode switch off/mono
8. Maintain line voltage at rated voltage.
9. LW antenna selector INT (LW-INT-RF Adjustment).
EXT (LW-EXT-RF Adjustment).
10. 300Ω FM dummy antenna Refer to fig. 3.
11. Output of signal generator should be no higher than necessary to obtain an output reading.

- Preparation of FM signal generator (FM-SG)

1. Connect stereo modulator to FM-SG.
2. Apply SG output to antenna terminal of the set through 300 Ω FM dummy antenna.

3. The standard input of the set is 60 dB (1mV), 400 Hz 100% modulation (Because of using dummy antenna, SG output must be 12 dB plus (1HF). That is, when input is 60 dB, SG output is to be 72 dB.)

Step No.	AM/FM SIGNAL GENERATOR		DIAL SETTING	INDICATOR (VTVM or SCOPE)	ADJUSTMENT POINTS	REMARKS
	CONNECTION	FREQUENCY				
	MW/LW IF ADJUSTMENT					
1	Connect AM-SG to AM antenna terminal through 200pF capacitor. Common to chassis. (Powerful input)	450kHz (30% Mod. with 400 Hz) (For United Kingdom to 468kHz)	Point of non-inter-ference	Connect AC VTVM or scope to "OUTPUT" terminals.	T201 (1st IFT) T202 (2nd IFT)	Adjust the input frequency and adjustment points so that the output becomes maximum.

AM/FM SIGNAL GENERATOR		DIAL SETTING	INDICATOR (VTVM or SCOPE)	ADJUSTMENT POINTS	REMARKS
CONNECTION	FREQUENCY				
MW-RF ADJUSTMENT					
Connect AM-SG to AM antenna terminal through 200pF capacitor. Common to chassis. (Weak input)	600kHz (30% Mod. with 400 Hz)	600kHz	Connect AC VTVM or scope to "OUTPUT" terminals.	L252 (MW OSC Coil) L250 (MW ANT Coil)	Adjust for maximum output. Adjust L250 (MW Coil) by moving coil bobbin along ferrite core.
	1500kHz (30% Mod. with 400 Hz)	1500kHz	Connect AC VTVM or scope to "OUTPUT" terminals.	CT202 (MW OSC Trimmer) CT201 (MW ANT Trimmer)	- Adjust for maximum output. - Repeat steps (2) and (3).
LW INT-RF ADJUSTMENT					
Connect AM-SG to AM antenna terminal through 200pF capacitor. Common to chassis. (Weak input)	145kHz (30% Mod. with 400 Hz)	145kHz	Connect AC VTVM or scope to "OUTPUT" terminals.	L253 (LW OSC Coil) L250 (LW INT ANT Coil)	- Adjust for maximum output. - Adjust L250 (LW Coil) by moving coil bobbin along ferrite core.
	350kHz (30% Mod. with 400 Hz)	350kHz	Connect AC VTVM or scope to "OUTPUT" terminals.	CT252 (LW OSC Trimmer) CT250 (LW INT ANT Trimmer)	- Adjust for maximum output. - Repeat steps (4) and (5).
LW EXT-RF ADJUSTMENT					
Connect AM-SG to AM antenna terminal through 200pF capacitor. Common to chassis. (Weak input)	145kHz (30% Mod. with 400 Hz).	145kHz	Connect AC VTVM or scope to "OUTPUT" terminals.	L251 (LW EXT ANT Coil)	Adjust for maximum output.
	350kHz (30% Mod. with 400 Hz)	350kHz	Connect AC VTVM or scope to "OUTPUT" terminals.	CT251 (LW EXT ANT Trimmer)	- Adjust for maximum output. - Repeat steps (6) and (7).
FM-IF ADJUSTMENT					
_____	No Signal	Point of non-interference	Connect DC VTVM between 17 and 18 terminal through choke coil. (Refer to Fig. 4)	T101 (Discri. IFT)	- FM muting/ mode switch to "on/auto" position. - Adjust T101 core so that voltage measured in signal mode is 0V in 300mV range.
FM-RF ADJUSTMENT					
Connect to FM 300Ω antenna terminal through 300Ω FM dummy antenna.	90MHz (100% Mod. with 400 Hz) weak input.	90MHz	Connect scope to "OUTPUT" terminal.	L4 (OSC Coil) L2 (RF DET Coil) L1 (ANT Coil)	- Add weak input so that noise is included in the output wave form. - Make the adjustment so that the output wave form is vertically symmetrical. (Fig. 5) - Repeat the steps (9) and (10) until the frequency correctly matches the dial scale.
	106MHz (100% Mod. with 400 Hz) weak input.	106MHz	Connect scope to "OUTPUT" terminal.	CT3 (OSC Trimmer) CT2 (RF DET Trimmer) CT1 (ANT Trimmer)	
FM MPX V.C.O ADJUSTMENT					
USING A FREQUENCY COUNTER			USING ALTERNATE SYSTEM		
1. 100MHz 60 dB Non-modulated mono signal applied to set. 2. FM muting/mode switch to "on/auto". 3. Connect frequency counter to TP301 through resistor (100kΩ). 4. Adjust VR301 to 19kHz ± 30 Hz.			1. Apply stereo signal from generator or stereo station to tuner. 2. Adjust VR301 until stereo indicator lights up. Cement arm of VR301 as shown in fig. 6.		

■ MESSUNGEN UND JUSTIERUNGEN Deutsch

(Für Deutschland) Darauf achten, die Justierung von MW und LW in der Reihenfolge der Schrittnummer vorzunehmen.

- **Stellungen und zu benutzende Geräte**

1. Elektronische Voltmeter für Wechsel- und Gleichstrom (VTVM).
2. AM (MW)-Meßsender (AM-SG)
3. UKW-Meßsender (FM-SG)
4. Oszilloskop
5. Signalfrequenzmesser (meßbar für 19kHz und 108MHz).
6. Bereichsschalter {AM (MW/LW Abgleich)
 {FM (UKW Abgleich)
7. FM Muting/Mode Schalter. off/mono.
8. Die Netzspannung auf ihren Sollwert einstellen.
9. LW-Antennenschalter. {INT (LW-INT-HF Abgleich)
 {EXT (LW-EXT-HF Abgleich)
10. UKW-Kunstantenne, 300 ohm Verl. Abb. 1.
11. Der Ausgang des Meßsenders darf nicht höher sein als unbedingt notwendig für eine gute ablesung.

- **Vorbereitung AM UKW-Messenger (FM-SG)**

1. Stereo-Modulator an FM-SG anschließen.
2. SG-Ausgang über 300-ohm UKW Konstantenne an den Antenneneingang des Gerätes schließen.
3. Der normale Eingang des Gerätes beträgt 60 dB (1mV), 400 Hz 100% Modulation. (Wegen Verwendung der Konstantenne muß der Signalausgang 12 dB plus (IHF) sein: d.h. beim Eingang von 60 dB soll der Signalausgang 72 dB sein.)

AM/UKW MESSENDER		SKALENZEI- GEREIN- STELLUNG DES TUNER	ANZEIGEGERÄT (Röhrenvoltmeter oder Oszillograph)	ABGLEICHS- PUNKTE	BEMERKUNGEN
ANSCHLUSS	FREQUENZ				
MW/LW-ZF-ABGLEICH					
Einen MW-Signal- generator über einen 200pF Kondensator mit dem MW-Antennenein- gang verbinden. Die gemeinsame Leitung mit dem Chassis verbinden. (Starker Eingang)	450kHz (400 Hz Modulat., 30%)	Kein Empfang	Wechselstrom Röhrenvolt- meter oder Oszillograph über den Ausgang "OUTPUT" schließen.	T201 (1. IFT) T202 (2. IFT)	Die Eingangsfrequenz und die Einstellungspunkte so adjustie- ren, daß der Ausgang den maximalen Wert erreicht.
MW-HF-ABGLEICH					
Einen MW-Signal- generator über einen 200pF Kondensator mit dem MW-Anten- neneingang verbinden. Die gemeinsame Leitung mit dem Chassis verbinden. (Schwacher Eingang)	600kHz (400 Hz Modulat., 30%)	600kHz	Wechselstrom Röhrenvolt- meter oder Oszillograph über den Ausgang "OUTPUT" schließen.	L252 (MW Osc. Spule) L250 (MW Ant. Spule)	• Auf max. Ausgang abgleichen. • L250 (MW Spule) wird abgleichen, in dem die Spule am Ferritstab entlang- geschoben wird.
	1500kHz (400 Hz Modulat., 30%)	1500kHz	Wechselstrom Röhrenvolt- meter oder Oszillograph über den Ausgang "OUTPUT" schließen.	CT202 (MW-Osc. Trimmer) CT201 (MW Ant. Trimmer)	• Auf max. Ausgang abgleichen. • Schritt (2) und (3) sind zu wiederholen.
LW INT-HF-ABGLEICH					
Einen MW-Signal- generator über einen 200pF Kondensator mit dem MW-Anten- neneingang verbinden. Die gemeinsame Leitung mit dem Chassis verbinden. (Schwacher Eingang)	145kHz (400 Hz Modulat., 30%)	145kHz	Wechselstrom Röhrenvolt- meter oder Oszillograph über den Ausgang "OUTPUT" schließen.	L253 (LW Osc. Spule) L250 (LW INT Ant. Spule)	• Auf max. Ausgang abgleichen. • L250 (LW Spule) wird abgleichen, in dem die Spule am Ferritstab entlanggeschoben wird.
	350kHz (400 Hz Modulat., 30%)	350kHz	Wechselstrom Röhrenvolt- meter oder Oszillograph über den Ausgang "OUTPUT" schließen.	CT252 (LW Osc. Trimmer) CT250 (LW INT Ant. Trimmer)	• Auf max. Ausgang abgleichen. • Schritt (4) und (5) sind zu wiederholen.
LW EXT-HF-ABGLEICH					
Einen MW-Signal- generator über einen 200pF Kondensator mit dem MW-Antennenein- gang verbinden. Die gemeinsame Leitung mit dem Chassis verbinden. (Schwacher Eingang)	145kHz (400 Hz Modulat., 30%)	145kHz	Wechselstrom Röhrenvolt- meter oder Oszillograph über den Ausgang "OUTPUT" schließen.	L251 (LW EXT Ant. Spule)	• Auf max. Ausgang abgleichen.
	350kHz (400Hz Modulat., 30%)	350kHz	Wechselstrom Röhrenvolt- meter oder Oszillograph über den Ausgang "OUTPUT" schließen.	CT251 (LW EXT Ant. Trimmer)	• Auf max. Ausgang abgleichen. • Schritt (6) und (7) sind zu wiederholen.
UKW-ZF-ABGLEICH					
—	Kein Signal	Kein Empfang	Ein Gleichstromröhren- voltmeter zwischen 17 und 18 über eine Drosselspule verbinden. (Siehe Abb. 2)	T101 (Diskriminator FT)	• FM muting/mode-Schalter auf "on/auto" stellen. • Den Kern von T101 so justieren, daß die gemessene Spannung im signallosen Modus 0V im 300mV Bereich beträgt.
UKW-HF-ABGLEICH					
Meßsender über eine Kunstantenne an den UKW-Antenneneingang schließen.	90MHz (400Hz Modulat., 100%) Schwacher- Eingang	90MHz	Oszillograph über den Ausgang "OUTPUT" schließen.	L4 (Osc. Spule) L2 (Det. Spule) L1 (Ant. Spule)	• Einen schwachen Eingang geben, bei dem Geräusch in der Ausgangswellen- form enthalten wird. • So einstellen, daß die Ausgangswellenform vertikal symmetrisch wird. (Abb. 3)
	106MHz (400 Hz Modulat., 100%) Schwacher Eingang	106MHz	Oszillograph über den Ausgang "OUTPUT" schließen.	CT3 (Osc. Trimmer) CT2 (Det. Trimmer) CT1 (Ant. Trimmer)	• Die Einstellung von (9), (10) wieder holen, bis die Frequenz mit der Skala übereinstimmt.
UKW-STEREO-DEKODER-ABGLEICH					
UNTER VERWENDUNG EINES ZÄHLERS			ALTERNATIV-MEß METHODE		
1. Unmoduliertes Mono-Signal 100MHz in das Gerät speisen. 2. FM muting/mode-Schalter auf "on/auto" stellen. 3. Zähler über einen Widerstand 100k ohm an TP301 schließen. 4. VR301 auf 19kHz ± 30 Hz einstellen.			1. Stereosignal entweder von einem Stereogenerator. oder einem Sender einspeisen. 2. VR301 so einstellen, bis die Stereolampe auf leuchtet. Schleifer von VR301 sichern, wie in Abb. 4 gezeigt.		

MESURAGES ET RÉGLAGES

■ Français

Veuillez régler PO et GO par ordre des numeros de procédlé

- **Réglage et équipement utilisé**

- [illegible]

7. Commutateur de silencieux/mode off/mono
8. Conserver la tension du secteur à la tension nominale.
9. Antenne selecteur LW (GO) INT (LW-INT Alignement).
 EXT (LW-EXT Alignement)
10. Antenne fictive FM 300Ω Voir fig. 3.
11. Le signal du générateur ne doit pas être plus élevé qu'il n'est nécessaire à obtenir une lecture en sortie.

- **Préparation du générateur de signal FM (FM-SG)**

1. Brancher la commande de réglage stéréophonique à FM-SG.
2. Alimenter la sortie SG à la borne de l'antenne de l'appareil, par l'antenne fictive FM, 300 ohms.

3. L'entrée standard de l'appareil est de 60 dB (1mV), 400Hz, 100% de modulation (à cause de l'utilisation de l'antenne fictive, la sortie SG doit être de plus 12 dB (1HF). Ce qui signifie que quand l'entrée est de 60 dB, la sortie SG doit être de 72 dB.)

AM/FM GENERATEUR		AIGUILLE SUR LE CADRAN	INDICATEUR (VOLT- METRE ELECTRONIQUE OSCILLOSCOPE)	POINTS DE REGLAGE	OBSERVATIONS
BRANCHEMENT	FREQUENCE				
ALIGNEMENT FI-MW (PO)-LW (G)					
No. 1	Brancher le AM-SG à la borne de l'antenne AM par un condensateur de 200pF. Commun au châssis. (Entrée sous puissante)	450kHz (modulé à 30% par 400 Hz)	Point sans signal	C.A. voltmètre électronique ou oscilloscope sur prise de sortie de l'appareil.	T201 (1 transfo FI) T202 (2 transfo FI) ● Régler la fréquence d'entrée et les points de réglage de telle sorte que la sortie devienne maximale.
ALIGNEMENT RF-MW (PO)					
2	Brancher le AM-SG à la borne de l'antenne AM par un condensateur de 200pF. Commun au châssis. (Entrée faible)	600kHz (modulé à 30% par 400 Hz)	600kHz	C.A. voltmètre électronique ou oscilloscope sur prise de sortie de l'appareil.	L252 (bobine OSC MW) L250 (bobine ANT MW) ● Réglez au maximum de signal de sortie. ● Régler L250 (bobine MW) en déplaçant la bobine le long du noyau de ferrite.
3		1500kHz (modulé à 30% par 400 Hz)	1500kHz	C.A. voltmètre électronique ou oscilloscope sur prise de sortie de l'appareil.	CT202 (trimmer OSC MW) CT201 (trimmer ANT MW) ● Réglez au maximum de signal de sortie. ● Recommencez les étapes (2) et (3).
ALIGNEMENT RF-LW (GO) INT					
4	Brancher le AM-SG à la borne de l'antenne AM par un condensateur de 200pF. Commun au châssis. (Entrée faible)	145kHz (modulé à 30% par 400 Hz)	145kHz	C.A. voltmètre électronique ou oscilloscope sur prise de sortie de l'appareil.	L253 (bobine OSC LW) L250 (bobine ANT LW INT) ● Réglez au maximum de signal de sortie. ● Régler L250 (bobine LW) en déplaçant la bobine le long du noyau de ferrite.
5		350kHz (modulé à 30% par 400 Hz)	350kHz	C.A. voltmètre électronique ou oscilloscope sur prise de sortie de l'appareil.	CT252 (trimmer OSC LW) CT250 (trimmer ANT LW INT) ● Réglez au maximum de signal de sortie. ● Recommencez les étapes (4) et (5).
ALIGNEMENT RF-LW (GO) EXT					
6	Brancher le AM-SG à la borne de l'antenne AM par un condensateur de 200pF. Commun au châssis. (Entrée faible)	145kHz (modulé à 30% par 400 Hz)	145kHz	C.A. voltmètre électronique ou oscilloscope sur prise de sortie de l'appareil.	L251 (bobine ANT LW EXT) ● Réglez au maximum de signal de sortie.
7		350kHz (modulé à 30% par 400 Hz)	350kHz	C.A. voltmètre électronique ou oscilloscope sur prise de sortie de l'appareil.	CT251 (trimmer ANT LW EXT) ● Réglez au maximum de signal de sortie. ● Recommencez les étapes (6) et (7).
ALIGNEMENT FI-FM					
8		Sans signal	Point sans signal	Brancher le voltmètre électronique a.c.c. aux bornes 17 et 18. (Voir la Fig. 4)	T101 (Transfo FI discri.) ● Commutateur de silencieux sur "on/auto". ● Régler le noyau T101 de telle sorte que le voltage mesuré dans le mode sans signal, soit de 0V dans la gamme des 300mV.
ALIGNEMENT RF-FM					
9	Branchez sur la prise d'antenne FM à travers une antenne fictive FM.	90 MHz (modulé à 100% par 400 Hz) Entrée faible	90 MHz	Oscilloscope sur prise de sortie du tuner.	L4 (bobine OSC) L2 (bobine DET) L1 (bobine ANT) ● Appliquer une entrée faible de telle sorte que le parasite soit compris dans la forme de l'onde de sortie. ● Faire le réglage de telle sorte que la forme de l'onde de sortie soit verticalement symétrique. (Voir fig. 5)
10		106 MHz (modulé à 100% par 400 Hz) Entrée faible	106 MHz	Oscilloscope sur prise de sortie du tuner.	CT3 (trimmer OSC) CT2 (trimmer DET) CT1 (trimmer ANT) ● Refaire les réglages (9) et (10) jusqu'à ce que la fréquence corresponde correctement avec l'échelle du cadran


ALIGNEMENT DU PILOTE MULTIPLEX FM

AVEC UN FRÉQUENCEMÈTRE

PAR UN OUTRE SYSTÈME


1. Signal mono 100MHz non modulé appliqué à l'appareil.
2. Commutateur de silencieux sur "on/auto".
3. Branchez le fréquencesmètre sur **TP301** à travers une
4. Réglez **VR301** sur $19\text{kHz} \pm 30\text{Hz}$.

1. Appliquez à l'appareil un signal stéréo provenant d'un générateur ou de la réception d'un émetteur.
2. Réglez **VR301** jusqu'à ce que l'indicateur de stéréophonie s'allume. Collez le curseur le **VR301** comme indiqué sur la fig. 6.




300Ω FM Dummy Antenna

[Fig. 3]
Abb. 1




- VR301**
- A - B, D - E: Stereo OFF Position.
 - B - D: Stereo ON Position (indicator Lighting).
 - C: Adjust Point of Pilot Circuit.

[Fig. 6]
Abb. 4




[Fig. 4]
Abb. 2




AF output wave form

[Fig. 5]
Abb. 3

ADJUSTMENT POINTS



■ BLOCK DIAGRAM



■ REPLACEMENT PARTS LIST Electrical Parts

Notes: 1. Part numbers are indicated on most mechanical parts. Please use this part number for parts orders.

2. Important safety notice:

Components identified by  mark have special characteristics important for safety.

When replacing any of these components, use only manufacturer's specified parts.


3. Bracketed indications in Ref. No. columns specify the area. Parts without these indications can be used for all areas.

Ref. No.	Part No.	Part Name & Description
INTEGRATED CIRCUIT		
IC101	RVIUCP1018CF	IC, FM IF Amp. AMRF Amp. AM Converter
IC102	SVIUCP1167C2	IC, FM IF Detector
IC103	SVIUCP1161C	IC, FM Multiplex
IC104	AN6136	IC, Muting
IC501	AN6876	IC, L.E.D Driver
IC502	AN6552F	IC, DC Amp
TRANSISTORS		
Q1	2SK195—H2	Transistor, FM RF Amplifier [FET]
Q2	25C1674—M	Transistor, FM Mixer
Q3	25C1675—L	Transistor, FM Oscillator
Q4	25C945—Q	Transistor, Switching
Q401	2SD762—O	Transistor, Regulator
DIODES		
D101, 202	20A90	Diode
D201, 203, 204	MA162A	Diode
D401	SVDEQA0113RA	Diode, 13V Zener
D402, 403	SVDSR1K2	Rectifier
D501 ~ 503, 510	MA162A	Diode
D504 ~ 508	LN420YP	Light Emitting Diode, Yellow
D509	LN220RP	Light Emitting Diode, Red
COILS and TRANSFORMERS		
L1	SLA4N15	Coil, FM Antenna
L2	SLD4P57—P	Coil, FM Detector
L3	ELQ5A77	Coil, Choke
L4	SLO4P95—P	Coil, FM Local Oscillator
L101	SLQX101—3M	Coil, Choke
L250	SLF6E9—O	Coil, AM Ferrite Bar Antenna
L251	SLA1C7	Coil, LW Antenna
L252	SLO2C1—P	Coil, MW Oscillator
L253	SLO1C13—P	Coil, LW Oscillator
L254, 255	RLQY15G5—O	Coil, Choke
T101	SLI4C521	Transformer, FM IF
T201	SLI2C129R—M	Transformer, AM IF
T202	SLI2C413R	Transformer, AM IF
T401	SLT5J141—W	Transformer, Power Source
CERAMIC FILTERS		
CF101, 102	SVFE107MM—A	Ceramic Filter, FM 10.7MHz Red
CF103, 104	SVFE107MM—B	Ceramic Filter, FM 10.68MHz Blue
	SVFE107MM—C	Ceramic Filter, FM 10.72MHz Orange
	SVFE107MZ2—A	Ceramic Filter, FM 10.7MHz Red
	SVFE107MZ2—B	Ceramic Filter, FM 10.675MHz Blue
CF201 CF201 [EK] only	SVFE107MZ2—C	Ceramic Filter, FM 10.725MHz Orange (Use pair ranks as same as CF101, CF102, CF103 and CF104)
	SVFSFU450B3	Ceramic Filter, AM 457kHz
	SVFSFU468B	Ceramic Filter, AM 475kHz
VARIABLE CAPACITORS		
VC1 ~ 3, 201, 202 (CT1 ~ 3, 201, 202)	ECV5MD34X71G	Variable Capacitor, FM & AM (With Trimmer)
CT250 ~ 252	SVCTY122D221	Trimmer, LW Antenna, Oscillator
VARIABLE RESISTOR		
VR301	EVTS3MA00B53	FM MPX VCO Adjustment
FUSES		
F1	Δ XBA2C06TR0	Fuse, T0.63A (250V)
F2	Δ XBA2C03TR0	Fuse, T0.315A (250V)
SWITCHES		
S1, 2	SSH2009	Switch, FM/AM Selector, Muting
S3	SSH187—1	Switch, FM IF Band
S4	SSH115	Switch, MW/LW Selector
S5	RSS42A	Switch, LW Antenna Selector
S6	ESE372	Switch, Voltage Adjuster
S8	Δ ESB90619A	Switch, Power Source

Ref. No.	Part No.	Part Name & Description
RESISTORS		
R1	ERD25TJ104	Carbon, 1/4W, 100kΩ, ± 5%
R2	ERD25FJ220	Carbon, 1/4W, 22Ω, ± 5%
R3	ERD25FJ221	Carbon, 1/4W, 220Ω, ± 5%
R4	ERD25TJ474	Carbon, 1/4W, 470kΩ, ± 5%
R5	ERD25FJ471	Carbon, 1/4W, 470Ω, ± 5%
R6	ERD25TJ393	Carbon, 1/4W, 39kΩ, ± 5%
R7	ERD25FJ102	Carbon, 1/4W, 1kΩ, ± 5%
R8	ERD25FJ103	Carbon, 1/4W, 10kΩ, ± 5%
R9	ERD25FJ102	Carbon, 1/4W, 1kΩ, ± 5%
R10	ERD25FJ181	Carbon, 1/4W, 180Ω, ± 5%
R11	ERD25TJ104	Carbon, 1/4W, 100kΩ, ± 5%
R101	ERD25FJ561	Carbon, 1/4W, 560Ω, ± 5%
R102	ERD25FJ471	Carbon, 1/4W, 470Ω, ± 5%
R103	ERD25FJ331	Carbon, 1/4W, 330Ω, ± 5%
R104	ERD25FJ471	Carbon, 1/4W, 470Ω, ± 5%
R105	ERD25FJ680	Carbon, 1/4W, 68Ω, ± 5%
R106	ERD25TJ184	Carbon, 1/4W, 180kΩ, ± 5%
R107	ERO25CKF3002	Metal Film, 1/4W, 30kΩ, ± 5%
R108	ERD25TJ393	Carbon, 1/4W, 39kΩ, ± 5%
R109	ERD25FJ682	Carbon, 1/4W, 6.8kΩ, ± 5%
R110	ERD25TJ333	Carbon, 1/4W, 33kΩ, ± 5%
R111	ERD25FJ182	Carbon, 1/4W, 1.8kΩ, ± 5%
R114	ERD25TJ333	Carbon, 1/4W, 33kΩ, ± 5%
R117	ERD25TJ123	Carbon, 1/4W, 12kΩ, ± 5%
R119	ERD25TJ563	Carbon, 1/4W, 56kΩ, ± 5%
R126	ERD25FJ392	Carbon, 1/4W, 3.9kΩ, ± 5%
R201	ERD25FJ103	Carbon, 1/4W, 10kΩ, ± 5%
R202	ERD25FJ392	Carbon, 1/4W, 3.9kΩ, ± 5%
R203	ERD25TJ333	Carbon, 1/4W, 33kΩ, ± 5%
R204	ERD25FJ272	Carbon, 1/4W, 2.7kΩ, ± 5%
R205	ERD25FJ471	Carbon, 1/4W, 470Ω, ± 5%
R206	ERD25FJ271	Carbon, 1/4W, 270Ω, ± 5%
R207, 208	ERD25TJ104	Carbon, 1/4W, 100kΩ, ± 5%
R209	ERD25FJ102	Carbon, 1/4W, 1kΩ, ± 5%
R210	ERD25TJ273	Carbon, 1/4W, 27kΩ, ± 5%
R211	ERD25TJ104	Carbon, 1/4W, 100kΩ, ± 5%
R212	ERD25FJ332	Carbon, 1/4W, 3.3kΩ, ± 5%
R223	ERD25FJ103	Carbon, 1/4W, 10kΩ, ± 5%
R224	ERD25FJ472	Carbon, 1/4W, 4.7kΩ, ± 5%
R302	ERD25FJ470	Carbon, 1/4W, 47Ω, ± 5%
R303, 304	ERD25TJ223	Carbon, 1/4W, 22kΩ, ± 5%
R305, 306	ERD25TJ473	Carbon, 1/4W, 47kΩ, ± 5%
R307	ERD25TJ274	Carbon, 1/4W, 270kΩ, ± 5%
R308	ERD25TJ153	Carbon, 1/4W, 15kΩ, ± 5%
R309	ERD25TJ473	Carbon, 1/4W, 47kΩ, ± 5%
R310	ERD25FJ391	Carbon, 1/4W, 390Ω, ± 5%
R311, 312	ERD25FJ332	Carbon, 1/4W, 3.3kΩ, ± 5%
R313, 314	ERD25TJ333	Carbon, 1/4W, 33kΩ, ± 5%
R316	ERD25FJ103	Carbon, 1/4W, 10kΩ, ± 5%
R317	ERD25FJ332	Carbon, 1/4W, 3.3kΩ, ± 5%
R320	ERD25TJ153	Carbon, 1/4W, 15kΩ, ± 5%
R321	ERD25TJ154	Carbon, 1/4W, 150kΩ, ± 5%
R322	ERD25TJ273	Carbon, 1/4W, 27kΩ, ± 5%
R323	ERD25TJ124	Carbon, 1/4W, 120kΩ, ± 5%
R324	ERD25TJ154	Carbon, 1/4W, 150kΩ, ± 5%
R325	ERD25TJ153	Carbon, 1/4W, 15kΩ, ± 5%
R326	ERD25TJ104	Carbon, 1/4W, 100kΩ, ± 5%
R327	ERD25FJ102	Carbon, 1/4W, 1kΩ, ± 5%
R401	ERD25FJ561	Carbon, 1/4W, 560Ω, ± 5%
R402	ERD25FJ681	Carbon, 1/4W, 680Ω, ± 5%
R501	ERD25FJ332	Carbon, 1/4W, 3.3kΩ, ± 5%
R502	ERD25FJ682	Carbon, 1/4W, 6.8kΩ, ± 5%
R503	ERD25TJ473	Carbon, 1/4W, 47kΩ, ± 5%
R504	ERD25TJ104	Carbon, 1/4W, 100kΩ, ± 5%
R505	ERD25FJ152	Carbon, 1/4W, 1.5kΩ, ± 5%
R506	ERD25TJ123	Carbon, 1/4W, 12kΩ, ± 5%
R507	ERD25TJ563	Carbon, 1/4W, 56kΩ, ± 5%
R508	ERD25TJ184	Carbon, 1/4W, 180kΩ, ± 5%
R509	ERD25FJ391	Carbon, 1/4W, 390Ω, ± 5%
R510	ERD25FJ122	Carbon, 1/4W, 1.2kΩ, ± 5%
R511	ERD25FJ272	Carbon, 1/4W, 2.7kΩ, ± 5%
R512	ERD25FJ100	Carbon, 1/4W, 10Ω, ± 5%


■ CIRCUIT BOARD AND WIRING CONNECTION DIAGRAM


Ground (Earth) lines



● Terminal guide of transistors, diodes and IC's

SV1μPC1018C, SV1μPC1167C2, SV1μPC1161C	AN6136, AN6876
AN6552	2SK195
2SC1674, 2SC1675, 2SC945	2SD762
LN417YP, LN217RP	LN220RP





SCHEMATIC DIAGRAM



(This schematic diagram may be modified at any time with the development of new technology.)

Notes:

- S1-1, 1-2:** FM muting/FM mode selector switch in "on/FM auto" position.
on/FM auto → off/FM mono
- S2-1, 2-2:** Band selector switch in "FM" position.
FM → AM
- S3-1, 3-2:** FM IF-band selector switch in "normal" position.
normal → super narrow
- S4-1, 4-2, 4-4:** AM band selector switch in "MW" position.
MW → LW (S4-5 is muting switch.)
- S5-1 ~ 5-4:** LW antenna selector switch in "INT" position.
INT → EXT
- S6:** Voltage selector switch in "240V" position.
① 110V → ② 120V → ③ 220V → ④ 240V
- S8:** Power switch in "on" position.
- Indicated voltage values are the standard values for the unit measured by the DC electronic circuit tester (high-impedance) with the chassis taken as standard. Therefore, there may exist some errors in the voltage values, depending on the internal impedance of the DC circuit tester.
* Figures in () stand for DC voltage in FM/AM signal reception mode.
* Figures in [] stand for DC voltage in FM stereo signal reception mode.
* Figures in { } stand for DC voltage in FM (no signal) muting to on mode.
* Figures in () stand for DC voltage with the band selectors circuit set at AM.
- Signal lines
→ FM signal
→ Audio frequency signal
→ Positive voltage lines
→ AM signal
- Important safety notice:
Components identified by mark have special characteristics important for safety. When replacing any of these components, use only manufacturer's specified parts.

Shorting Switch

This unit uses a shorting switch. As illustrated below, the circuit is shorted to the next circuit without being opened. In the circuit diagram, the shaded area represents the common terminal.



Continued from page 10

Ref. No.	Part No.	Part Name & Description			
CAPACITORS					
C1	ECCD1H150K	Ceramic,	50V, 15pF,	± 10%	
C2	ECCD1H070D	Ceramic,	50V, 7pF,	± 0.5pF	
C3	ECKD1H102ZF	Ceramic,	50V,0.001μF,	± 80%	
C4	ECCD1H030C	Ceramic,	50V, 3pF,	±0.25pF	
C5	ECCD1H150K	Ceramic,	50V, 15pF,	± 10%	
C6	ECCD1H060C	Ceramic,	50V, 6pF,	±0.25pF	
C7	ECCD1H181K	Ceramic,	50V, 180pF,	± 10%	
C8	ECKD1H103ZF	Ceramic,	50V, 0.01μF,	± 80%	
C9	ECCD1H390KC	Ceramic,	50V, 39pF,	± 10%	
C10	ECCD1H150KC	Ceramic,	50V, 15pF,	± 10%	
C11	ECKD1H102ZF	Ceramic,	50V,0.001μF,	± 80%	
C12	ECEA1CS330	Electrolytic,	16V, 33μF		
C101, 102	ECKD1H103ZF	Ceramic,	50V, 0.01μF,	± 80%	
C103, 104	ECKD1H103ZF	Ceramic,	50V, 0.01μF,	± 80%	
C105	ECEA25Z4R7	Electrolytic,	25V, 4.7μF		
C106	ECEA50Z1	Electrolytic,	50V, 1μF		
C107	ECCD1H101K	Ceramic,	50V, 100pF,	± 10%	
C108	ECEA50Z1	Electrolytic,	50V, 1μF		
C109	ECKD1H103ZF	Ceramic,	50V, 0.01μF,	± 80%	
C110	ECEA1CS330	Electrolytic,	16V, 33μF		
C111	ECKD1H223ZF	Ceramic,	50V,0.022μF,	± 80%	
C112, 113	ECKD1H103ZF	Ceramic,	50V, 0.01μF,	± 80%	
C114	ECEA1HS100	Electrolytic,	50V, 10μF		
C115	ECCD1H030C	Ceramic,	50V, 3pF,	±0.25pF	
C116	ECCD1H103ZF	Ceramic,	50V, 0.01μF,	± 80%	
C117	ECCD1H470K	Ceramic,	50V, 47pF,	± 10%	
C119	ECKD1H103ZF	Ceramic,	50V, 0.01μF,	± 80%	
C202	ECCD1H150KC	Ceramic,	50V, 15pF,	± 10%	
C203	ECP1361JZ	Polypropylene,	100V, 360pF,	± 5%	
C204	ECKD1H103ZF	Ceramic,	50V, 0.01μF,	± 80%	
C205	ECEA1HS100	Electrolytic,	50V, 10μF		
C206	ECEA25Z4R7	Electrolytic,	25V, 4.7μF		
C207, 208	ECKD1H103ZF	Ceramic,	50V, 0.01μF,	± 80%	

Ref. No.	Part No.	Part Name & Description				
C210	ECKD1H103ZF	Ceramic,	50V, 0.01μF,	± 80%		
C212	ECQM1H223KZ	Polyester,	50V, 0.022μF,	± 10%		
C213	ECKD1H103ZF	Ceramic,	50V, 0.01μF,	± 80%		
C214	ECEA1HS100	Electrolytic,	50V, 10μF			
C215	ECEA50Z1	Electrolytic,	50V, 1μF			
C216	ECKD1H103ZF	Ceramic,	50V, 0.01μF,	± 80%		
C223	ECKD1H103MD	Ceramic,	50V, 0.01μF,	± 20%		
C224	ECCD1H220K	Ceramic,	50V, 22pF,	± 10%		
C250	ECCD1H070D	Ceramic,	50V, 7pF,	± 0.5pF		
C251	ECCD1H030C	Ceramic,	50V, 3pF,	± 0.25pF		
C253	ECQS1181JZ	Styrol,	125V, 180pF,	± 5%		
C254	ECCD1H680KC	Ceramic,	50V, 68pF,	± 10%		
C301	ECEA25Z4R7	Electrolytic,	25V, 4.7μF			
C302	ECQM1H473KZ	Polyester,	50V, 0.047μF,	± 10%		
C303	ECEA1ES101	Electrolytic,	25V, 100μF			
C305, 306	ECKD1H271KB	Ceramic,	50V, 270pF,	± 10%		
C307	ECEA50Z4R7	Electrolytic,	50V, 0.47μF			
C308	ECEA50Z1	Electrolytic,	50V, 1μF			
C310	ECQP1471JZ	Polypropylene,	100V, 470pF,	± 5%		
C311, 312	ECQM1H153KZ	Polyester,	50V, 0.015μF,	± 10%		
C313, 314	ECEA50Z4R7	Electrolytic,	50V, 0.47μF			
C315, 316	ECKD1H103ZF	Ceramic,	50V, 0.01μF,	± 80%		
C317	ECEA1ES470	Electrolytic,	25V, 47μF			
C401	ECEA1CS331	Electrolytic,	16V, 330μF			
C402	ECEA1VS221	Electrolytic,	35V, 220μF			
C404, 405	ECEA1CS331	Electrolytic,	16V, 330μF			
C406	ECKD1H103ZF	Ceramic,	50V, 0.01μF,	± 80%		
C407	ECKD1H271KB	Ceramic,	50V, 270pF,	± 10%		
C408	ECKDKC103PF	Ceramic,	400VAC, 0.01μF,	± 100%		
C501	ECEA50Z1	Electrolytic,	50V, 1μF			
C502	ECEA1ES101	Electrolytic,	25V, 100μF			
C503	ECEA1HS470	Electrolytic,	50V, 47μF			
C504	ECEA25Z4R7	Electrolytic,	25V, 4.7μF			
C505	ECEA50Z4R7	Electrolytic,	50V, 0.47μF			
C506, 507	ECKD1H103ZF	Ceramic,	50V, 0.01μF,	± 80%		
C508	ECKD1H103ZF	Ceramic,	50V, 0.01μF,	± 80%		

REPLACEMENT PARTS LIST Cabinet & Chassis Parts

- Notes:**
- Part numbers are indicated on most mechanical parts. Please use this part number for parts orders.
 - Important safety notice: Components identified by **Δ** mark have special characteristics important for safety. When replacing any of these components, use only manufacturer's specified parts.
 - Bracketed indications in Ref. No. columns specify the area. Parts without these indications can be used for all areas.


Areas

- * [EK] is available in United Kingdom.
- * [EF] is available in France.
- * [EB] is available in Belgium.

Ref. No.		Part No.	Part Name & Description
CABINET and CHASSIS PARTS			
1		SGWTS2LE	Front Panel Ass'y
2		SBN1043	Knob, Tuning
3		SHP671-1	Spacer, Knob
4		SBC337	Button, Power Source
5		SDZ051-2	Cord, Dial 180 cm
6		SWV5-2	Pointer, Dial
7		SHP15-2	Spacer, Pointer
8		SBC409	Button, Push Switch
9		SGU233	Transparent Cover
10		SUFTS2LE	Front Sub Panel Ass'y
11		SKC790S	Cabinet Cover
12		RJT202B	Terminal
13		SJT347	Terminal, Fuse
14		SDR3	Roller
15		SUR125	Bracket, Roller
16		SUG67	Guide, Pointer
17		SUB73	Coupling Rod
18		SUB71	Coupling Rod
19		SUB69	Coupling Rod
20		SDT8083	Shaft, Tuning Ass'y (W/Flywheel)
21		SUR123	Bracket, Roller
22		SHE73	Spacer, P C B
23		SJF3247-1N	Terminal, Output
24		SGP2630-2E	Rear Panel (Made in Japan)
24 [EF] only	JPN	SGP2630-2E	Rear Panel (Made in Japan)
24 [EF] only	MLK	SGP2630-2F	Rear Panel (Made in England)
25		SHR127	Bushing, AC Cord
25 [EK] only		SHR129	Bushing, AC Cord
26	△	SJA88	AC Cord
26 [EK] only	△	QFC1205M	AC Cord
27		SHR401-1	Lock Pin, P.C.B
28		SJF4419-4	Terminal, Antenna

Ref. No.		Part No.	Part Name & Description
29		SHG711	Spacer
30		SDD47-1	Drum, Dial
31		SDSA4121	Spring, Dial
32		SKU9111	Bottom Board
33		SKL249	Foot
34		SHR9527-1	Spacer
SCREWS, WASHERS and NUT			
N1		XTB3+8BFZ	Screw, Tapping, $\oplus 3 \times 8$
N2		XNS11	Nut, $\phi 11$
N3		XWD11B	Washer, External Toothed Lock $\phi 11$
N4		XSN3+6S	Screw, $\oplus 3 \times 6$
N5		XWA3B	Washer, Spring $\phi 3$
N6		XTB4+8BFN	Screw, Tapping $\oplus 4 \times 8$
N7		XTN3+8B	Screw, Tapping $\oplus 3 \times 8$
N8		XWC3B	Washer, External Toothed Lock $\phi 3$
N9		XTB3+8BFZ	Screw, Tapping $\oplus 3 \times 8$
N10		SHD3X21F-1	Screw
N11		XTS3+8B	Screw, Tapping $\oplus 3 \times 8$
N12		XTN3+10B	Screw, Tapping $\oplus 3 \times 10$
N13		XWG3	Washer, Plain, $\phi 3$
N14		XWC3B	Washer, External Toothed Lock $\phi 3$
N15		XTB3+8BFN	Screw, Tapping $\oplus 3 \times 8$
N16		XTB3+10BFZ	Screw, Tapping $\oplus 3 \times 10$
N17		XTN3+8B	Screw, Tapping $\oplus 3 \times 8$
N18		XWG3	Washer, Plain $\phi 3$
N19		XTN3+10BFZ	Screw, Tapping $\oplus 3 \times 10$
N20		XWG3FZ	Washer, Plain $\phi 3$
N21		XTN3+12B	Screw, Tapping $\oplus 3 \times 12$
N22		SHD3X27	Screw
ACCESSORIES			
A1		SSA267	Cord, FM Indoor Antenna
A2		SJP2129-5	Cord, Connection
A3		SQF10791	Instruction Book, Printed Matter

EXPLODED VIEW



EXPLODED VIEW

& Description	
✓, 0.01μF, ±80%	
✓, 0.022μF, ±10%	
✓, 0.01μF, ±80%	
✓, 10μF	
✓, 1μF	
✓, 0.01μF, ±80%	
✓, 0.01μF, ±20%	
✓, 22pF, ±10%	
✓, 7pF, ±0.5pF	
✓, 3pF, ±0.25pF	
✓, 180pF, ±5%	
✓, 68pF, ±10%	
✓, 4.7μF	
✓, 0.047μF, ±10%	
✓, 100μF	
✓, 270pF, ±10%	
✓, 0.47μF	
✓, 1μF	
✓, 470pF, ±5%	
✓, 0.015μF, ±10%	
✓, 0.47μF	
✓, 0.01μF, ±80%	
✓, 47μF	
✓, 330μF	
✓, 220μF	
✓, 330μF	
✓, 0.01μF, ±80%	
✓, 270pF, ±10%	
AC, 0.01μF, ±100%	
✓, 1μF	
✓, 100μF	
✓, 47μF	
✓, 4.7μF	
✓, 0.47μF	
✓, 0.01μF, ±80%	
✓, 0.01μF, ±80%	

gdom.

& Description	
3 x 8	
bothed Lock φ11	
4 x 8	
3 x 8	
bothed Lock φ3	
3 x 8	
3 x 10	
bothed Lock φ3	
3 x 8	
3 x 10	
3 x 8	
3 x 10	
3 x 12	
antenna	
inted Matter	

Ref. No.	Part No.	Part Name & Description
PACKING PARTS		
P1	SPP649	Polyethylene Bag
P2	SPS3073-2	Pad, Left Side
P3	SPS3075-2	Pad, Right Side
P4	SPG3095	Carton Box
P4 [EF] only	SPG3097	Carton Box (Made in Japan)
P4 [EF] only	SPG2991	Carton Box (Made in England)

